

StarDomes™ IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:

Read all instructions before using this furnishing.

DANGER - To reduce the risk of electric shock:

1. Always turn off power to this furnishing before cleaning.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Turn off power to this furnishing before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has damaged electrical connections, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Do not use outdoors.
6. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

"WARNING: Risk of Electric Shock - Connect this furnishing to a properly grounded outlet only. See Wiring Instructions."

SAVE THESE INSTRUCTIONS

Installation Instructions for Stardomes™

Questions? Call us! (760) 931-2550 / (888) 611-3663 / www.numinus.com / Numinus, LLC

Install Drop-Down Molding (surface mount) or prepare ceiling per Rough-In drawing sheet (flush mount). Installation over bathtub requires GFCI protected circuit.

PREPARATION

1. Inspect all items. Report any damage immediately to Numinus, LLC.
2. Fit check dome in ceiling (or Drop-Down Molding [DDM]) and mark mounting holes. (Holes may already exist in DDM.) Ensure that the mounting screws will be threading into structure.
3. Remove the junction box with two 2-prong outlets in it from the dome flange. (The low voltage power supply may already be plugged in.)
4. Remove inner plate (with outlets) from the box.

INSTALL DOME

▪ TURN OFF POWER

5. Hold dome in place and fasten to ceiling framing where holes were marked, (route electrical wires through rectangular hole for junction box.)
6. Insert switch leg wires through romex connector into junction box. Tighten romex connector snug.
7. Reattach junction box to dome flange.

WIRE JUNCTION BOX

8. Wire grounds and neutrals per code.
9. Connect Star Power Supply outlet black wire to one only switch leg.
10. Connect Cove Light black wire to LED cove Light power supply switch leg (not necessary if cove light power supply is remotely located).

(for wiring of LED Controller refer to NuLEDs SD232 Operations Manual)

11. Fasten outlet plate back into junction box.
12. Plug power supply and cove light (If using outlet to power) into their outlets. Feed low voltage connector through the hole in junction box. Plug it into the circuit board through the hole in the circuit board enclosure.
13. Power up and test cove light controller and stars.

INSTALL TRIM RING

14. Slide black plastic spin clips into aluminum anchors on dome flange as follows:
 - Insert the head of the spin clip under the anchor with the neck of the spin clip in the slot of the anchor.
 - Rotate the spin clip to align the flats on the tip (and neck) of the spin clip with the slot in the anchor.
 - With your thumb and finger close to the neck of the spin clip, slide the spin clip into receiver until it snaps into place in the center on the anchor.
15. Align marked circle on inside of trim ring with circle cut out in dome flange.
16. Align each spin clip with cylinder receivers on trim ring. (View from inside dome.)
17. Push trim ring up to engage spin clips. (Spin clips ratchet into place. Push under each one a couple of times to fully seat.)
18. Caulk seams. (Optional, recommended for finished look)

PAINT TRIM RING AND VISIBLE PART OF SOFFIT AS DESIRED

CARE OF STARDOMES™

- TO CLEAN SURFACE OF DOME USE SOFT BRUSH AND VACUUM HOSE. HOLD THE VACUUM HOSE AWAY FROM THE SURFACE OF THE DOME AND BRUSH DEBRIS INTO IT.

CAUTION

- DO NOT USE ANY CLEANING SOLUTIONS ON PAINTED SURFACE OF DOME.
- WIPING SURFACE OF DOME MAY DAMAGE FIBER OPTIC STARS.

THANK YOU FOR PURCHASING A STARDOME!

Toll Free Support: (888) 611-DOME

www.numinus.com

Numinus, LLC